Refrigerator

User manual

36"

Free Standing Appliance





Untiled-18

(

9

1022-01-19 306 7:06-1




Door bins

Your refrigerator ships with door bins of different types and sizes. If the door bins for your refrigerator were packaged separately, use the figure below to help you position the bins properly.

NOTE

The actual refrigerator and provided component parts of your refrigerator may differ from the illustrations in this manual, depending on the model and the country.



18 English —

+

2022-01-19 3017-06-54

Step-by-step installation


STEP 1 Select a site

The site must:

- Have a solid level surface without carpeting or flooring that may obstruct ventilation
- Be out of direct sunlight

- Have adequate room for opening and closing the door Be away from any heat source Provide room for maintenance and servicing Have a temperature range between 50 °F (10 °C) and 110 °F (43 °C)

See the following figures and tables for installation space requirements.



Model	RF23BB8*****	RF29BB8*****
Α	28 ⁶ / ₆ " (730 mm)	34 ¹ / ₄ " (868 mm)
В	35 %" (9	908 mm)
С	68 ³/s" (1	749 mm)
D	70" (17	78 mm)

- English 19




Gas Cooktop Installation manual

NA30N6555T*/NA30N7755T* NA36N6555T*/NA36N7755T*




haall_NA30N6555TG_DG68-01091A-02_EN+MES+CFR indb - 1

Overall cooktop dimensions



		1			
NA36N7755T	NA36N6555T*	NA30N7755T*	NA30N6555T*	Model	grate surface
(914.4 mm)	36"	(762 mm)	30"	A	
(855 mm)	3311/16"	(715 mm)	281/8"	В	21' (533 mm)
(479 mm)	18 ⁷ /8"	(492.1 mm)	193/8"	C	223/ ₆ " (568 mm)

Cutout dimensions of countertop




NA36N6555T 33/8" NA36N7755T (85.7 mm)	NA30N6555T* 27/8" NA30N7755T* (73 mm)	Model (D) Min.
19¹/a" (485.8 mm)	195/a" (498.5 mm)	(E) Min.
33 [*] / ₈ " (860.4 mm)	28 ¹ / ₂ " (723.9 mm)	(F) Min.
12" (304.8 mm)	12" (304.8 mm)	(G) Min.

Installation dimensions with downdraft hood

NOTE


- Make sure the clearance dimensions when you install the cooktop with downdraft hood.
- The cooktop can be installed after detaching Smart Connect module. Please refer to the instruction how to detach Smart Connect module on page 15.



NA36N6555T* NA36N7755T*	NA30N6555T* NA30N7755T*	Model
3" (76 mm)	2 ⁷ /16" (62 mm)	(H) Min.

Installation requirements


Single Oven Under counter



- O1 This cooktop can be installed above any Samsung single built-in oven. Refer to installation manual of oven.
- O2 Gas and Electrical Connections for Gas Cooktop Must be Located in an Adjacent Accessible Location to the Right.

WIII. 22 (MIII 33.9 CIII)		F 24" (61 cm)	Min. 271/s"/ Max. 273/s" (Min. 69.2 cm / Max. 69.5 cm)	D Min. 1"/ Max. 11/4" (Min. 2.5 cm / Max. 3.2 cm)	C Min. 28 ¹ / ₃ "/ Max. 28 ⁵ / ₆ " (Min. 72.4 cm / Max. 72.7 cm)	B 4" (10.1 cm)	A Min. 3 ³ / ₄ " (9.5 cm)	Size
Many O'L" (Many O'L) and throat on Day	.9 cm)		.2 cm / Max. 69.5 cm)	cm / Max. 3.2 cm)	.4 cm / Max, 72,7 cm)		cm)	

Utility locations and dimensions



Gas supply requirements

Provide adequate gas supply

This cooktop is designed to operate at a pressure of 5 in (13 cm) of water column on natural gas or 10 in (25 cm) of water column on LP gas (propane or butane).

Make sure you are supplying your cooktop with the type of gas for which it is designed. Do not attempt to convert the appliance from the gas specified in this manual to a different gas without consulting the gas supplier.

This cooktop is convertible for use on natural or propane gas. If you decide to use this cooktop on LP gas, conversion must be made by a qualified LP installer before attempting to operate the cooktop.

For proper operation, the pressure of natural gas supplied to the regulator must be between 5 in and 13 in (13 cm and 33 cm) of water column.

For LP gas, the pressure supplied must be between 10 in and 13 in (25 cm and 33 cm) of water column.

When checking for proper operation of the regulator, the inlet pressure must be at least 1 in (2.5 cm) greater than the operating (manifold) pressure as given.

Install_NA30N6555TG_DC64-01091A-02_EN+MES+CFR indb=12

•

The pressure regulator located at the inlet of the cooktop manifold must remain in the supply line regardless of whether natural or LP gas is being used.



- The cooktop comes from the factory with a regulator in the shipping carton. Use only the regulator provided. The regulator must be installed in the gas line that runs from the cooktop gas inlet to the gas shut off valve.
- An external manual shut-off valve must be installed between the gas inlet and the cooktop for the purpose of turning on or shutting off gas to the appliance.
- Be sure the connectors are installed when you need coupling by a qualified installer.

Never reuse old connectors when installing the cooktop. The use of old

connectors can cause gas leaks and personal injury. Always use new flexible connectors when installing a gas appliance.

Special gas requirements (gas models sold in Massachusetts)

COMMONWEALTH OF MASSACHUSETTS REQUIREMENTS:

WARNING

Gas leaks may occur in your system, creating a dangerous situation

- Gas leaks may not be detected by smell alone.
- Gas suppliers recommend you purchase and install a UL-approved gas detector Gas detector should be installed in accordance with the manufacturers instructions.
- Cooktop must be installed by a qualified plumber or gas fitter by the State of Massachusetts.
- A T-handle manual gas valve MUST be installed in the gas supply line to your cooktop.
- If a flexible gas connector is used to install your cooktop, multiple flexible gas lines must not be connected in series.

Electrical requirements

■ WARNING

- It is the owner's responsibility to make sure that the electrical service meets electrical requirements and that he electrical outlet has been properly installed by a licensed electrician.
- To reduce the risk of fire, electric shock, or personal injury:


II cooktops


- Do not use an extension cord or adapter plug with this cooktop
- This cooktop must be properly grounded.
- Check with a qualified electrician if you are in doubt as to whether your cooktop is properly grounded.
- Do not modify the plug provided with your cooktop if it doesn't fit the outlet have a proper outlet installed by a qualified electrician.
- All wiring and grounding must be done in accordance with local codes or, in the absence of local codes, with the National Electrical Code, ANSI/NFPA No. 70 – Latest Revision (for the U.S.) or the Canadian Electrical Code CSA C22.1 – Latest Revisions and local codes and ordinances.
- Wiring diagram is located on the inside of the burner box.
- This cooktop is equipped with an electronic ignition system that will not operate
 if plugged into an outlet that is not properly polarized.

Installation requirements

Gas cooktops

- All gas models are equipped with a power cord with an equipment-grounding conductor and a grounding plug.
- A 120-Volt, 60-Hz, AC, approved electrical service with 20-amp circuit breaker or time-delay fuse is required for all U.S. and Canadian models.





Important Safety Instructions

Venting Methods

To use the hood's top outlet to vent your hood, a 6" (15.2 cm) round vent system is required. To use the hood's rear outlet, a 31/4" \times 10" (8.25 \times 25.4 cm) rectangular vent system is required. Neither of these vent systems are included and must be purchased separately.

purchased separately.

(a) NOTE

(b) NOTE

Flexible vents are not recommended. Flexible vents create back pressure and air turbulence that greatly reduces performance. The vent system can terminate either through the roof or a wall. To vent through a wall, a 90 * elbow is needed.

Mounting Height

Select a mounting height between a minimum of 24" (61 cm) for an electric cooking surface, a minimum of 27" (68.6 cm) for a gas cooking surface, and a suggested maximum of 36" (91.4 cm) above the range to the bottom of the hood.


Rear discharge
A 90 ° elbow may be installed immediately above the hood.

For Non-Vented (recirculating) Installations

If it is not possible to vent cooking fumes and vapors to the outside, the hood can be used in the non-vented (recirculating) version, fitting a charcoal filter and a plastic grid. Fumes and vapors are recycled through the recirculation grid.

Installation Requirements

General Specifications




English


MANUAL INSTALL_Range Hood_DG68-01500A.indb

Mounting Height

⚠ CAUTION


- Be sure to check the mounting height before installing the product
- The mounting height is measured from the top of the range to the upper the image on the right. the mounting height is measured from the top of the burning grates as shown in its glass cooktop as shown in the image on the left. For a gas cooking surface, cabinets. The mounting height for an electric cooking surface is measured from





Venting Methods

Smoke is exhausted to the outside through a special pipe connected to the hood



ELECTRIC RANGES

GAS RANGES

- The minimum connectable exhaust outlet diameter is 6" (15.2 cm).
- Ensure the exhaust outlet diameter and duct diameter match, and then connect the duct to the wall outlet.
- If the duct and the wall outlet have different diameters, the suction performance will decrease while also significantly increasing noise.
- Use the minimum possible length for the duct, and do not significantly alter the The manufacturer is not responsible for any problems caused by this.
- When connecting the duct, minimize bending. (Max bending angle: 90")
- In an environment where installing with an external venting method is possible. be sure to install only using the external venting method.



Step-by-step installation


STEP 1 Select a site

The site must:

- Have a solid level surface without carpeting or flooring that may obstruct ventilation
- · Be out of direct sunlight
- Have adequate room for opening and closing the door
- Be away from any heat source
- · Provide room for maintenance and servicing
- Have a temperature range between 50 °F (10 °C) and 110 °F (43 °C)

Clearance

See the following figures and tables for installation space requirements.



Model	RF23BB8*****	RF29BB8*****
Α	28 ⁶ /s" (730 mm)	34 ¹ / ₄ " (868 mm)
В	35 6/8" (9	908 mm) ==
С	68 ⁷ /s" (1	749 mm)
D	70" (17	78 mm)



On 43



Installation manual



Location requirements

IMPORTANT: Observe all governing codes and ordinances


- Recessed installation area must provide complete enclosure around the Given dimensions provide minimum clearance with oven. Cabinet opening dimensions that are shown must be used
- recessed portion of the oven.
- Grounded electrical supply is required. See "Electrical connection" section
- minimum diameter hole should have been drilled in the right rear or left Electrical supply junction box should be located 3" (7.6 cm) maximum below junction box. rear corner of the support surface to pass the appliance cable through to the the support surface when the oven is installed in a wall cabinet. A 1" (2.5 cm)

in the upper Right of the cabinet. wall behind oven, it is recommended that the junction box be recessed and located in the adjacent right or left cabinet. If you are installing the junction box on rear For under counter installation, it is recommended that the junction box be located

- Oven support surface must be solid, level and flush with bottom of cabinet
- Floor must be able to support a Combi. oven weight of at least 249.1 lb (113 kg) (NQ70"600D"AA) / 260.1 lb (118 kg) (NQ70"700D"AA). (exclude accessories)

allowable wood cabinet temperatures of 194 °F (90 °C). requirements of UL and CSA International and complies with the maximum or sustain other damage. This oven has been designed in accordance with the cabinet supplier to make sure that the materials used will not discolor, delaminate IMPORTANT: To avoid damage to your cabinets, check with your builder or

Product dimensions - Combi. ovens



		DIMENSION
Α	43¹/₄" (109.9 cm)	Overall height
8	281/2" (72.4 cm)	Recessed width
С	42" (106.5 cm)	Recessed height
ם ס	26 ⁵ / ₈ " (67.6 cm)	Overall depth (with Handle)
D-1	23¹/ʁ" (58.7 cm)	Recessed depth
D-2	24 ³ / ₈ " (62.0 cm)	Overall depth
Е	29³/₄" (75.6 cm)	Door Width
'n	67" (170 cm)	Conduit length
G)	27 ¹⁵ / ₁₆ " (70.9 cm)	Overall width (Handle width)
Ŧ.	2½" (5.6 cm)	Handle Depth

'Not for NQ70""700D" AA lower oven door


Preparation

Cabinet dimensions - Combi. ovens

Combi Ovens Installed in Cabinet

1 Junction Box

Allow a minimum of 22" for clearance to adjacent corners, drawers, walls, etc. when door is open



FI	П	D	С	В	Α	Cabinet
42¹/₄" (107.2 cm)	Min. 1"/ Max. 1 ¹ / ₄ " (Min. 2.5 cm / Max. 3.2 cm)	Min. 28 ¹ / ₂ "/ Max. 28 ⁵ / ₈ " (Min. 72.4 cm / Max. 72.7 cm)	12" (30.5 cm)	Min. 1 ³ / ₁₆ " (3.0 cm)	30" (76.2 cm)	DIMENSION

Cabinet	DIMENSION
G	Min. 231/ ₃ " (Min. 59.7 cm)
н	Min 301/2" (Min 755 mm)
1	Max. 91/2" (Max. 24.1 cm) - Junction Box
ل	Min. 11/16" (1.75 cm) - Wooden cabinet thickness

If codes permit and a separate ground wire is used, it is recommended that a qualified electrical installer determine that the ground path and the wire gauge are in accordance with local codes.

Those with a qualified electrical installer if you are not sure the over is prepared.

Check with a qualified electrical installer if you are not sure the oven is properly grounded.

This oven must be connected to a grounded-metal permanent wiring system. Be sure that the electrical connection and wire size are adequate and in conformance with the National Electrical Code, ANSI/NFPA 70-latest edition or CSA Standards C22.

local codes and ordinances.

1-94, Canadian Electrical Code, Part 1 and C22.2 No. 0-M91-latest edition, and all

A copy of the above code standards can be obtained from:

National Fire Protection Association
1 Batterymarch Park

Quincy, MA 02169-7471

CSA International
8501 East Pleasant Valley Road


Cleveland, OH 44131-5575

DG68-01560A-00_IM_NQ70xx700D.6000xxAA_EN+MES+CFR.indb 6

Electrical Connection

To properly install your oven, you must determine the type of electrical connection you will be using and follow the instructions provided in this manual.

Oven must be connected to the proper electrical voltage and frequency as specified on the model/serial/rating plate. The model/serial/rating plate is located below the control panel on combi ovens. See the following illustrations.



Combi. oven

A. Model/serial/rating plate

- A circuit breaker is recommended.
- Use the chart below to determine the minimum recommended dedicated circuit protection.

		מידה (הבתובמיבת)
≤4.8 KW	≤4.1 KW	20 Amp
4.9 KW - 7.5 KW	4.3 KW - 6.2 KW	30 Amp
7.3 KW - 9.6 KW	6.3 KW - 8.3 KW	40 Amp
9.7 KW - 12.0 KW	8.4 KW - 10.4 KW	50 Amp

Connect directly to the circuit breaker box (or fused disconnect) through flexible, armored or nonmetallic sheathed, copper cable (with grounding wire). See "Electrical Connection" section.

- Flexible conduit from the oven should be connected directly to the junction box.
- Fuse both sides of the line.
- Do not cut the conduit. The length of conduit provided is for serviceability of the oven.
- A UL listed or CSA approved conduit connector must be provided.
- If the house has aluminum wiring, follow the procedure below:
- Connect a section of solid copper wire to the ends of the flexible conduit leads.
- Connect the aluminum wiring to the added section of copper wire using special connectors and/or tools designed and UL listed for joining copper to aluminum.

Follow the electrical connector manufacturer's recommended procedure.

Aluminum/copper connection must conform with local codes and industry accepted wiring practices.

For power requirements for models NQ70**600D**AA, and NQ70**700D**AA refer

to the following table.		
A Code	240 VAC	208 VAC
Miodei	MA	WA
NQ70**600D**AA	8.2	6.2
NQ70"700D"AA	9.5	7.2