

# **APPLIANCE CHECKLIST**

It may seem early to be thinking about appliances, but they are an important part of your kitchen design and may require upgrades to your HVAC, plumbing and electrical plans. It's important that we are provided with your appliance information during the structural and foundation part of the Design Process, so that these upgrades can be included on your invoice, if required.

FRIDGE  DISHWASHER  CAFE  CAFE  CDT875P4NW2  RANGE  CAFE  CCHS950P4MW2  Type: Gas	ITEM	BRAND		MODEL NUMBER
RANGE	FRIDGE	CAFE		CWE19SP4NW2
Type: Gas	DISHWASHER	CAFE		CDT875P4NW2
Electrical: 15 Amp         40 Amp         50 Amp         Waterline Required           Type:         Gas         Electric         Waterline Required           Electrical:         30 Amp         40 Amp         Waterline Required           WARMING DRAWER         NA         Waterline Required         Waterline Required           Electrical:         15 Amp         Other: Specify         Waterline Required           COOKTOP         NA         Waterline Required         Waterline Required           Type:         Gas         Induction         Waterline Required           Type:         Gas         Induction         Waterline Required           Induction         Waterline Required         Waterline Required           Induction         Waterline Required         Amp           Induction         Unduction         Caterline           BUILT IN MICROWAVE         CAFE         CWL112P4RW5           Electrical:         15 Amp         120 Volt         120 Volt           MICROWAVE TRIM KIT         NA         NA           WASHING MACHINE         LG         WKEX200HBA           WKEX200HBA         You         Stacked           Type:         Gas         Electric         Stacked           OTH	RANGE	CAFE		CCHS950P4MW2
WALL OVEN Type: Gas	·· <u> </u>		Induction [	✓ Waterline Required ☐
Type: Gas	Electrical: 15 Amp	40 Amp 🔽	50 Amp	
Electrical: 30 Amp	WALL OVEN	NA		
WARMING DRAWER    Selectrical: 15 Amp				Waterline Required
Electrical: 15 Amp  Other: Specify  COOKTOP  NA  Type: Gas  Electric  Induction  Electrical: 15 Amp  50 Amp  Electrical: 15 Amp  20 Amp  240 Volt  120 Volt  MICROWAVE TRIM KIT  NA  OTR MICROWAVE NA  WASHING MACHINE  LG  WKEX200HBA  Type: Gas  Electric  Stacked  Stacked  Stacked  Stacked  Stacked  Stacked  COTHER: HOODFAN  CYCLONE  BX21228  OTHER: WINE FRIDGE  CAFE  CCCP06BP4PW2	Electrical: 30 Amp	40 Amp		
Type: Gas ☐ Electric ☐ Induction ☐ Electrical: 15 Amp ☐ 40 Amp ☐ 50 Amp ☐ Electrical: 15 Amp ☐ 20 Amp ☑ 240 Volt ☑ 120 Volt ☐ MICROWAVE TRIM KIT NA  OTR MICROWAVE NA  WASHING MACHINE LG WKEX200HBA  Type: Gas ☐ Electric ☐ Stacked ☑ OTHER: HOODFAN CYCLONE BX21228  OTHER: WINE FRIDGE CAFE CCP06BP4PW2	WARMING DRAWER	NA		
Type: Gas	Electrical: 15 Amp	Other: Specify		
BUILT IN MICROWAVE  CAFE  CWL112P4RW5  Electrical: 15 Amp  20 Amp  20 Amp  240 Volt  MICROWAVE TRIM KIT  NA  OTR MICROWAVE  NA  WASHING MACHINE  LG  WKEX200HBA  Type: Gas  Electric  Stacked  OTHER: HOODFAN  CYCLONE  BX21228  CCP06BP4PW2	COOKTOP	NA		
BUILT IN MICROWAVE  Electrical: 15 Amp	"· <u> </u>	Electric	Induction [	
Electrical: 15 Amp         20 Amp         240 Volt         120 Volt           MICROWAVE TRIM KIT         NA         NA           OTR MICROWAVE         NA         WKEX200HBA           WASHING MACHINE         LG         WKEX200HBA           DRYER         LG         WKEX200HBA           Type:         Gas         Electric         Stacked           OTHER: HOODFAN         CYCLONE         BX21228           OTHER: WINE FRIDGE         CAFE         CCP06BP4PW2	Electrical: 15 Amp	40 Amp	50 Amp	
MICROWAVE TRIM KIT  OTR MICROWAVE  NA  WASHING MACHINE  LG  WKEX200HBA  DRYER  LG  WKEX200HBA  Type: Gas   Electric   Stacked   OTHER: HOODFAN  CYCLONE  BX21228  OTHER: WINE FRIDGE  CAFE  CCP06BP4PW2	<b>BUILT IN MICROWAVE</b>	CAFE		CWL112P4RW5
OTR MICROWAVENAWASHING MACHINELGWKEX200HBADRYERLGWKEX200HBAType:GasElectricStackedOTHER: HOODFANCYCLONEBX21228OTHER: WINE FRIDGECAFECCP06BP4PW2	Electrical: 15 Amp	20 Amp 🔽	240 Volt 🕨	120 Volt
WASHING MACHINE       LG       WKEX200HBA         DRYER       LG       WKEX200HBA         Type:       Gas       Electric       Stacked       ✓         OTHER:       HOODFAN       CYCLONE       BX21228         OTHER:       WINE FRIDGE       CAFE       CCP06BP4PW2	MICROWAVE TRIM KIT	NA		
DRYER     LG     WKEX200HBA       Type:     Gas     ☐     Stacked ✓       OTHER: HOODFAN     CYCLONE     BX21228       OTHER: WINE FRIDGE     CAFE     CCP06BP4PW2	OTR MICROWAVE	NA		
Type: Gas	WASHING MACHINE	LG		WKEX200HBA
OTHER: HOODFANCYCLONEBX21228OTHER: WINE FRIDGECAFECCP06BP4PW2	DRYER	LG		WKEX200HBA
OTHER: WINE FRIDGE CAFE CCP06BP4PW2	Type: Gas	Electric		Stacked 🗸
	OTHER: HOODFAN	CYCLONE		BX21228
OTHER:	OTHER: WINE FRIDGE	CAFE CCP06BP4PW2		
	OTHER:			

Hood Fans must be purchased through Phoenix Homes, and will require an upgrade to a make up air system for any hood fans above 300CFM. Standard hood fan vent pipe is 6".

A make up air system is a required upgraded for all gas stoves/cooktops.

Any changes from the standard kitchen plan and/or standard electrical, plumbing and electrical specifications/plans may be subject to additional fees.

Community: DIAMONDVIEW (3) Lot #: 114

Purchaser Signature: Purchaser Signature:

Rosa Brown

# Café<sup>™</sup> Built-In Microwave Drawer Oven

CWL112P4RW5 / CWL112P2RS1 / CWL112P3RD5













CWL112P2RS1

CWL112P3RD5 Matte Black

### **FEATURES & BENEFITS**

Sensor Cook & Sensor Reheat - Microwave sensor cooking automatically adjusts the time and power for delicious results with packaged foods, leftovers and more.

Glass Touch Controls - Sleek touch controls make this smart microwave easy to use and clean.

Drawer Door - This easy open microwave extends like a cabinet drawer and sits lower than a typical countertop unit for added convenience and easy access.

Electronic Open - Simply push a button to open the handleless microwave door.

 $1.2\;\text{cu.}$  ft. - This mid-sized microwave has plenty of capacity thanks to the innovative drawer design.

Convenient Controls - Quickly microwave your favorites with ease using intuitive cooking controls.

# **FEATURES**

Control Type	Glass Touch
Electronic Digital Display with Clock	Yes
Style	Built-In
Interior Oven Light	Incandescent
Power Levels	10
	Popcorn Potato Chicken Fish
	Meat
	Vegetable - Fresh
Microwave Sensor	Vegetable - Frozen
Cooking Controls	Vegetable - Canned
	Add 30 Sec Mute On/Off Start/Pause Clear/Off Lock controls Power Level Timer Set Clock Express Cook Weight/Time Defrost Cook Time Open Close Melt Soften Beverage Popcorn Sensor Reheat
Control Features	Sensor Cook
Microwave Oven Interior	Coated
Microwave Watts (IEC-705)	1,000W

# CAPACITY

Total Capacity (cubic feet)	1.2 cu ft

# TECHNICAL DETAILS

Electrical Input - 120V Watts	1500	
Input Volts/Hertz	120/60	

# WEIGHTS & DIMENSIONS

Approximate Shipping Weight	80 lb
Cabinet Width	24 in
Cavity (W x H x D)	17-1/4 x 7-1/8 x 17-1/2
Net Weight	69 lb
Overall Depth	23-5/16 in
Overall Height (Rear)	14-19/32 in
Overall Height (Front)	15-15/16 in
Overall Width	23-7/8 in

# WARRANTY

	Limited 1-year entire appliance
Parts warranty	Limited 5-year magnetron tube
Labor warranty	Limited 1-year entire appliance
Warranty notes	See written warranty for full details

# Café<sup>™</sup> Built-In Microwave Drawer Oven

CWL112P4RW5 / CWL112P2RS1 / CWL112P3RD5




## DIMENSIONS AND INSTALLATION INFORMATION (IN INCHES)


# **OVERALL DIMENSIONS**


# 23 23/32" (6.3) 22 11/16" (57.6) 3 5/32" 15 23/32" 16.3) FRONT VIEW (SHOWING CUTOUT OVERLAP) 23 1/4" (59.1) 19 1/16" (48.4) 2 9/16" 3 3/16" (5.5) SIDE VIEW 21 9/16" 3 9/16" (5.5) 15 15/16" TOP VIEW 21 5/8" 21 5/8"

## STANDARD INSTALLATION



## **FLUSH INSTALLATION**





 $\boxed{\mbox{\ensuremath{\mathbb{A}}}}$  Junction box location (May also be located in adjacent cabinet.)

OPEN DRAWER SHOWING CLEARANCE

B To reduce the risk of tipping of the drawer, the Anti-Tip block must be properly installed located 14-13/16" above the floor on which the Microwave Drawer will sit. The Anti-Tip block must be provided and pre-installed by the purchaser of the product or builder before install can be done. The Anti-Tip block prevents serious injury that might result from spilled hot liquids.

15 3/32"

- Cleats may be visible and should be finished to match cabinetry.
- The face of the shelf must sit 1-7/8" back from the face of the cabinet. See installation instructions for further details including the installation of 24" flush mount deflector vent.

Dimensions in parentheses are in centimeters unless otherwise noted. Actual product dimensions may vary due to manufacturing tolerances.

# Café<sup>™</sup> Stainless Interior Built-In Dishwasher with Hidden Controls

CDT875P4NW2 / CDT875P3ND1 / CDT875P2NS1





CDT875P4NW2 Matte White with Brushed Bronze handles



### ALSO AVAILABLE IN



CDT875P3ND1 Matte Black with Brushed Stainless handles



CDT875P2NS1 Stainless Steel with Brushed Stainless handles

### **FEATURES & BENEFITS**

Ultra Wash & Dry Plus – Expect precision cleaning and superior dryness on fine china, dinnerware and even dishwasher-safe plastics, with exceptional features like Variable-Pressure Jets and Dual-Convection Ultra Dry

Loading Flexibility – Clean up quickly after hosting any event with a dishwasher that accommodates large items – like charcuterie platters – and dishwasher-safe plastics, like storage containers, conveniently in the lower

Status Center – Continue conversations without interruption and easily know when extra dinnerware is available via an LCD screen that displays the dishwasher cycle status


Adjustable Upper Racks – You'll have room for your finest stemware and space for tall bakeware with a rack that can be moved two inches up or down, creating ultimate loading flexibility

WiFi – Always have clean dishes ready for surprise guests with WiFi Connect, which lets you operate your dishwasher from your smartphone. Track and automatically reorder detergent and rinse aid with just the tap of an app

Create a look that matches your personal style – Select any combination of premium finishes and hardware options to create a stunning look customized to any owner's taste

# APPEARANCE

Door Style	Long Door with Top Controls
Installation	Side Installation or Top Installation Included; Built-Up Floor Capable; Flush Cabinet Installation
Door Appearance	Full-length flat door



# **ECONOMICAL/QUIET**

Exterior Style

Racking System

Quiet Package	39 dBA
Quiet Features	Quiet Water Valve; Sealed Toe Kick; Tub Collar Trim
Motor Type	Variable Speed
Outer Wrap	Full-wrap Blanket; Bitumen
Door Insulation	Insulation; Mastic

Traditional

Full 3rd Rack

# **WEIGHTS & DIMENSIONS**

Cabinet Width	24 in
Approximate Shipping Weight	137 lb
Net Weight	124 lb
Overall Height	34 in
Height w/ Legs Retracted - Minimum Height	33-3/8 in
Height w/Legs Extended - Maximum Height	34-5/8 in
Overall Depth	24 in
Overall Width	23-3/4 in



# Café<sup>™</sup> Stainless Interior Built-In Dishwasher with Hidden Controls

CDT875P4NW2 / CDT875P3ND1 / CDT875P2NS1




### TECHNICAL DETAILS

I LOITH TO IL D	ETHES
Calrod Heater Watts	400/1200
Power Connection	Optional cord kit (GPFCORD - WX09X70910, WX09X70911)
Volts/Hertz/Amps	120 V; 60 Hz; 10.2 A


## WARRANTY

Parts warranty	Limited 1-year entire appliance
Labor warranty	Limited 1-year entire appliance
Warranty notes	See written warranty for full details

# **DIMENSIONS**



# INSTALLATION DIMENSIONS



# ADDITIONAL ACCESSORIES



Brushed Bronze CXADTH1PMBZ (Standard on Matte White)



Brushed Stainless CXADTH1PMSS (Standard on Matte Black and Stainless steel)



Brushed Black CXADTH1PMBT



Brushed Copper CXADTH1PMCU

# Café<sup>™</sup> Energy Star<sup>®</sup> 18.6 Cu. Ft. Counter-Depth French-Door Refrigerator

CWE19SP4NW2 / CWE19SP3ND1 / CWE19SP2NS1





ALSO AVAILABLE IN

CWE19SP2NS1 with Brushed Stainless handles



CWE19SP3ND1 Matte Black with Brushed Stanless handles

CWE19SP3ND1 Matte Black with Brushed Stanless handles









# **FEATURES & BENEFITS**

Enjoy the aesthetic and amenities of a French-door refrigerator that fits in a 33-inch opening

Create a built-in look with  ${\bf counter\text{-}depth\ design}$  that fits flush with surrounding cabinetry

Enjoy a cleaner appliance appearance with internal water dispenser

Display groceries like a gallery with  $\textbf{showcase} \ \textbf{LED} \ \textbf{lighting}$  positioned throughout the interior to spotlight your favorite foods and containers

Easily store your farmer's market veggies and fresh fruits in **two humidity**controlled drawers, and place large items like party platters and sheet cakes in a full-width, adjustable-temperature drawer

Open the door as often as you need to while cooking or attending to guests and trust the  $\textbf{Turbo}\ \textbf{Cool}\ \textbf{setting}$  to make adjustments that will properly maintain the refrigerator's interior temperature

Spend less time looking for your favorite frozen foods thanks to  ${\it multi-level}$ freezer baskets that make organization easy

Choose your refrigerator's exact temperature using easily adjustable controls with a digital actual temperature display, stored in-the-door for a subtle, hidden appearance

Make room for tall items like milk and fruit juice with a **Quick Space shelf** that slides away usefully

Enjoy water and ice from the refrigerator with total peace of mind, thanks to an advanced water filtration system that uses RPWFE replacement filters to remove 98% of pharmaceuticals  $^{\ast}$ 

Removes 98% of ibuprofen, atenolol, fluoxetine, progesterone and trimethoprim. These pharmaceuticals are not necessarily in all users' water.

# APPEARANCE

IN I EMUNICE		
Counter-depth design	Yes	
Exterior design	Contoured doors	
Handle design	Café™	
Hidden door hinges	Yes	

# EEATLIDES

FEAT UKES		
Configuration	French door	
WiFi connect	ConnectPlus	
Temperature management features	Turbo cool setting; Multiflow air system with electronic sensors	
Defrost type	Frost Guard	
Control type	Upfront electronic temperature controls; Digital temperature display	
Dispenser	Internal water	
Icemaker	Factory-installed	
Water filtration	GE water filtration 6 month; XWF; water filter indicator light	
Filter location	Upper right corner	
Door alarm	Yes	
Fresh food cabinet drawers	Multi-level drawers; 2 humidity controlled drawers; 1 full-width, adjustable temperature drawer	
Fresh food cabinet shelves	5 total; glass; 4 split adjustable; 1 Quick Space shelf	
Fresh food door bins	8 Clear Look; 6 adjustable with gallon storage; 2 fixed	
Fresh food features	Interior lighting - dual level LED	
Freezer storage baskets	2 total; 1 full-width, full-extension plastic	
Freezer cabinet drawer features	Freezer drawer	
Freezer features	Interior lighting - LED; ice bucket	
Exterior style	Counter-depth	
Leveling system	2 point front adjustable	
Performance features	Easily removable door gaskets	

# CAPACITY

Total capacity (cubic feet)	18.6 cu. ft.	
Fresh food capacity	13.57 cu. ft.	
Freezer capacity	5.01 cu. ft.	

# **WEIGHTS & DIMENSIONS**

Overall depth	31 in
Overall height	69-7/8 in.
Overall width	32-3/4 in.
Case depth without door	24-1/8 in.
Depth with door open 90°	42-in.
Depth without handle	29-in.
Height to top of case	68-5/8 in.
Height to top of hinge	69-3/4 in.
Width w/door open 90° incl. handle	40-1/2 in.
Approximate shipping weight	252 lb.
Net weight	232 lb.



# Café<sup>™</sup> Energy Star<sup>®</sup> 18.6 Cu. Ft. Counter-Depth French-Door Refrigerator





CWE19SP4NW2 / CWE19SP3ND1 / CWE19SP2NS1

## WARRANTY

Parts warranty	Limited 1-year entire appliance
Labor warranty	Limited 1-year entire appliance
Warranty notes	See written warranty for full details

# **DIMENSIONS**





	Height to top of door (in.) A	69-7/8
Height to top of hinge (in.) B		69-3/4
	Height to top of case (in.) C  Case depth without door (in.) D  Case depth less door handle (in.) E  Case depth with door handle (in.) F	
ı⊒8l		
NSI		
S H		
	Depth with fresh food door open 90° (in.) <b>G</b>	42
	Width (in.) H	32-3/4
	Width with door open 90° with door handle (in.) I	40-1/2
AIR CLEARANCES	Each side (in.)	1/8
AIR	Top (in.)	1
CLE/	Back (in.)	2

# ADDITIONAL ACCESSORIES



CXMA3H3PNBZ Brushed Bronze 3 handles (Standard on Matte White)



CXMA3H3PNSS Brushed Stainless 3 handles (Standard on Matte Black and Stainless Steel)



CXMA3H3PNBT Brushed Black 3 handles



CXMA3H3PNCU Brushed Copper 3 handles

# Electric Slide-In Ranges Installation Instructions

82

Questions? Visit cafeappliances.com. In Canada, visit cafeappliances.ca.


# **BEFORE YOU BEGIN**

Read these instructions completely and carefully.

- instructions for local inspector's use IMPORTANT — Save these
- IMPORTANT Observe all governing codes and ordinances.
- Note to Installer Be sure to leave these instructions with consumer.
- Note to consumer Keep these instructions for future reference.
- requires a qualified installer or electrician. Skill level – Installation of this appliance
- Proper installation is the responsibility of the installer.
- Product failure due to improper installation is not covered under warranty.

# 2 PREPARE THE OPENING (FOR INDOOR USE ONLY)

See illustrations for all rough-in and spacing dimensions. The range may be placed with 0" clearance (flush) at the back wall and side walls of the cabinet.



NOTE: Use a 4' power cord to prevent interference with have to be dressed to allow for proper drawer closing. the storage drawer. Power cords 41/2 to 6' long may

off at service panel and lock the service

If you did not receive an anti-tip bracket with your purchase visit cafeappliances.com (In Canada, cafeappliances.ca).

to children or adults.

When the service disconnecting means disconnecting means to prevent power

from being switched on accidentally.

prominent warning device, such as a

ag, to the service panel.

cannot be locked, securely fasten a

beginning the installation, switch power

Before

**AWARNING** 

Engage the range to the anti-tip bracket by sliding the Re-engage the anti-tip bracket if the range is moved, Failure to do so can result in death or serious burns

· A child or adult can tip the range and be killed, Install the anti-tip bracket to the wall or floor. range back such that the foot is engaged.

**AWARNING** 

**FOR YOUR SAFETY** 

Anti-Tip Bracket

Kit Included

# WALLS AND ABOVE THE COOKTOP:

A. Make sure the wall covering, countertop, flooring and cabinets around the range can withstand the heat (up to 200°F) generated by the range. 0" to

Sides Both

> and bottom of unprotected wood or metal cabinet, or Allow 30" minimum clearance between surface units allow a 24" minimum when bottom of wood or metal cabinet is protected by no less than 1/4" thick flame retardant millboard covered with not less than No. 28 MSG sheet metal, (.015"), .015" thick stainless

> > **Fape Measure**

Tin Snips

Drill with 1/8" Bit

1/4" Nut Driver

Pliers

1

adjacent surfaces above the cooktop. However, a 6" minimum spacing to surfaces less than 15" above the cooktop and adjacent cabinet is recommended to reduce exposure to steam, grease C. This appliance has been approved for 0" spacing to splatter and heat.

above the cooktop should be avoided. If cabinet storage space is to be provided above the cooktop, the risk can be reduced by installing a range hood that projects at least 5" beyond the front of the To reduce the risk of burns or fire when reaching over hot surface elements, cabinet storage space cabinets. Cabinets installed above the cooktop must be no deeper than 16".

# MINIMUM DIMENSIONS BETWEEN COOKTOP,

- cabinets below cooktop and at the range back,
- steel, .024" aluminum or .020" copper.

# REMOVE PACKAGING MATERIALS: Failure to remove packaging racks, heating elements and drawer. Also, remove protective film and labels on the outer materials could result in damage to the appliance. Remove all packing parts from oven, door, cooktop and control panel.

# MATERIALS YOU MAY NEED

**FOOLS YOU WILL NEED** 

Adjustable Wrench Safety Glasses Level

4-Wire Cord 4' long OR (UL Listed 40 AMP) 3-Wire Cord 4' long

Squeeze Connector (For Conduit

Installations Only)

# **ELECTRICAL REQUIREMENTS**

# **AWARNING**

This appliance must be properly grounded,

# **▲** WARNING

# **▲**WARNING

To prevent fire or shock, do not use an extension cord with this appliance.

where local codes do not allow grounding through neutral, require a 4-conductor UL-listed range cord.

All new constructions, mobile homes, recreational vehicles and installations

# beginning installation

**AWARNING**To prevent shock, remove house fuse or open circuit breaker before

electrician. After installation, have the electrician show you how to disconnect power from the range. connect to aluminum wiring, properly installed connectors approved for use with aluminum wiring We recommend you have the electrical wiring and hookup of your range connected by a qualified You must use a single-phase, 120/208 VAC or 120/240 VAC, 60 hertz electrical system. If you must be used. Effective January 1, 1996, the National Electrical Code requires that new construction (not existing) construction, mobile home, recreational vehicle, or an area where local codes prohibit grounding through the neutral conductor, refer to the section on four-conductor branch circuit connections. utilize a 4-conductor connection to an electric range. When installing an electric range in new

Check with your local utilities for electrical codes which apply in your area. Failure to wire your oven according to governing codes could result in a hazardous condition. If there are no local codes, your oven must be wired and fused to meet the National Electrical Code, NFPA No. 70 – latest edition, available from the National Fire Protection Association.

individual, properly grounded, 40 amp (minimum) branch circuit protected by a circuit breaker or This appliance must be supplied with the proper voltage and frequency, and connected to an time-delay fuse. Use only a 3-conductor or a 4-conductor UL-listed range cord. These cords may be provided with ring terminals on wire and a strain relief device.

is not recommended but if used, it should be marked for use with nominal 11%" diameter connection A range cord rated at 40 amps with 125/250 minimum volt range is required. A 50 amp range cord openings. Care should be taken to center the cable and strain relief within the knockout hole to keep the edge from damaging the cable.

The rating plate is located on the oven frame or on the side of the drawer frame.

**NOTE**: Use of automatic, wireless or wired external switches that shut off power to the appliances, are not recommended for this product.


# DOUBLE OVEN

Rating plate

# 4 | POWER CORD AND CONDUIT INSTALLATION

can access the terminal block by either removing a terminal block cover (on some models) or Remove wire cover (on the back of range) by removing screws using a 1/4" nut driver. You the wire cover. Do not discard these screws. 4

# Rear of Range




For power cord and 1" conduit only, remove the knockout ring (13%") located on bracket directly below the terminal block. To remove the knockout, use a pair of pliers to bend the knockout ring away from the bracket and twist until ring is removed. В

ပ

For power cord installations only (see the next step if using conduit), assemble the strain relief in the hole. Insert the power cord through the strain relief and tighten. Allow enough slack to easily attach the cord terminals to the terminal block. If tabs are present at the end of the winged strain relief, they can be removed for better fit.

reinstalling the rear range wiring cover without a strain relief. The strain relief NOTE: Do not install the power cord bracket MUST be installed before

Terminal block (appearance—may vary)



Knockout ring .

removed


Knockout

ring in bracket-

**Terminal** 

For 3/4" conduit installations only, purchase a squeeze connector matching the diameter of your conduit and assemble it in the hole, Insert the conduit through the squeeze connector and tighten. Allow enough slack to easily attach the wires to the terminal block. NOTE: Do not install the conduit without a squeeze connector. The squeeze connector MUST be installed before reinstalling the rear terminal block, ۵


Power cord -



Proceed to step 6 or 7.

# 5 REAR TRIM INSTALLATION

For all installations, install the required rear trim to back of range with 4 screws provided.



# 6 3-WIRE INSTALLATION (GROUND IS THROUGH THE **NEUTRAL WIRE)**

# **AWARNING** Shock Hazard

properly grounded. Do not remove the ground strap. =ailure follow this instruction may result in potential connected as shown below for the range to be The neutral wire and ground strap must be shock hazard.

# **AWARNING** Fire hazard

Terminal block screws must be securely tightened. Failure to do so may result in potential fire hazard.

Ground strap

plate

# FOR POWER CORD INSTALLATION

- A. Remove the 3 lower screws from the terminal block. Do not loosen the upper screws.
- B. Do not cut or remove the ground strap.
- terminal ring and back into the terminal block. Be certain the white wire is in the center. Securely C. Insert the 3 screws through each power cord tighten each screw (35 to 50 in-lbs.)

Power cord


Red o Black

# FOR CONDUIT INSTALLATION

- A. Loosen the 3 lower screws on the terminal block. Do not loosen the upper screws.
- B. Do not cut or remove the ground strap.
- C. Insert the bare wire tip (insulation stripped 5/8") into the wire is in the center. On certain models, the wire must Securely tighten each screw onto each wire (35 to 50 bottom terminal block openings. Be certain the white be inserted through an opening in the ground strap.
- D. Reinstall terminal block cover.

NOTE: Aluminum building wire may be used but it must be rated for the correct amperage and voltage.

PROCEED TO STEP 8.



# ∐ 4-WIRE INSTALLATION (SEPARATE GROUND WIRE)

Terminal be connected to the lower left and the lower block of the terminal block. The power leads must frame of the range with the ground plate and **AWARNING**The neutral wire of the supply circuit must be connected to the neutral terminal located in the lower center right terminals of the terminal block. The grounding lead must be connected to the the green ground screw.

# FOR POWER CORD INSTALLATION

Ground strap

0

ō

**©** 

50

**Ground strap** 

Before-Power Cord and Conduit

- terminal block. Do not loosen the upper A. Remove the 3 lower screws from the
- B. Remove the ground screw and ground plate and retain them,

**Power Cord** 

**Terminal block** 

(appearance may vary) —

terminal Ground-

Neutral

After-Power Cord

Neutral terminal

- C. Cut the ground strap below the terminal block and discard the lower section.
- D. Insert the ground screw through the ground range frame. Tighten securely, but do not plate (removed earlier) and back into the over-tighten (15 to 20 in-lbs.)
- terminal block. Be certain the white wire is in the center. Securely tighten each screw power cord terminal ring and back into the E. Insert the 3 terminal screws through each 35 to 50 in-lbs.


↑ Red or Black


F Reinstall terminal block cover

# FOR CONDUIT INSTALLATION

White

- A. Remove the 3 lower screws from the terminal block. Do not loosen the upper screws.
  - B. Remove the ground screw and ground plate and retain them.
- C. Cut the ground strap below the terminal block and discard the lower section.
- stripped 5/8") between the range frame and the D. Insert the bare ground bare wire tip (insulation place with the ground screw. Tighten securely, ground plate (removed earlier) and secure it in but do not over-tighten (15 to 20 in-lbs).
- Insert the wire tips (insulation stripped 5/8") into the bottom terminal block openings. Be certain models, the wire must be inserted through an each screw onto each wire (35 to 50 in-lbs.)
- NOTE: Aluminum building wire may be used but it must be rated for the correct amperage and voltage.





Reinstall terminal block cover.

# 8 ANTI-TIP DEVICE INSTALLATION



- A child or adult can tip the range and be killed. Install the anti-tip bracket to the wall or floor.
- Engage the range to the anti-tip bracket by sliding the range back such that the foot is engaged.
  - Re-engage the anti-tip bracket if the range is moved, Failure to do so can result in death or serious burns to children or adults.
- under the anti-tip bracket. If the range is pulled from the wall for any reason, always repeat this


range, the range must be secured by with the bracket for complete details See installation instructions shipped a properly installed anti-tip bracket, To reduce the risk of tipping the before attempting to install. To check if the bracket is installed and the range to see that the rear leveling engaged properly, look underneath

leg is engaged in the bracket. On some models, the storage drawer or kick panel can be removed for easier inspection. If visual inspection is not possible, slide the range forward, confirm the antiprocedure to verify the range is properly secured by the anti-tip bracket. Never completely remove tip bracket is securely attached to the floor or wall, and slide the range back so the leveling leg is he leveling legs or the range will not be secured to the anti-tip bracket.


# 9 LEVEL THE RANGE

remove the leveling leg as the range will not be secured to the anti-tip device properly. A WARNING Never completely

- A. Plug in the unit.
- B. Measure the height of your countertop at the rear of the opening (X).
- C. Adjust two rear leveling legs so that the rear of cooktop is at the same height or higher than the counter (Y).
- D. Slide unit into place.
- Install oven shelves in the oven and position the range where it will be installed.
- level on one of the oven shelves. Take two readings—with the level placed diagonally first in one direction and then the other, F. Check for levelness by placing a spirit
- Adjust front leveling legs until the range is
- leg is fully engaged with the anti-tip device. If not, remove the unit and adjust the height of the rear leg so that it is properly engaged. H. Look under the unit and verify that the rear



NOTE: Cooktop must be at or above counter.



# 10 FINAL INSTALLATION CHECKLIST

- Check to make sure the circuit breaker is closed (RESET) or the circuit fuses are replaced.
- Be sure power is in service to the building.
- Check that all packing materials and tape have been removed. This will include tape on metal panel under control knobs (if applicable), adhesive tape, wire ties, cardboard and protective plastic. Failure to remove these materials could result in damage to the appliance once the appliance has been turned on and surfaces have heated.
- Check that the door and drawer are parallel to each other and that both operate smoothly. If they do not, see the Owner's Manual for proper replacement.
- Check to make sure that the rear leveling leg is fully inserted into the Anti-Tip bracket and that the bracket is securely installed.

# **OPERATION CHECKLIST**

- Check that the oven control operates properly. If the oven control does not operate properly, recheck the wiring connections.
- Be sure all range controls are in the OFF position before leaving the range.

31-11059-1 06-18 GEA CHS950P, CES750P, and CHS995 INSTALLATION INSTRUCTION

# **LG LAUNDRY**

# WKEX200H\_A / WKGX201H\_A

Single Unit LG WashTower™ with Center Control™ 4.5 cu. ft. Front Load Washer and 7.4 cu. ft. Dryer

Ultra Large Capacity 4.5 cu. ft. Washer and 7.4 cu. ft. Dryer Single Unit WashTower $^{\text{\tiny TM}}$  Design

Full Touch Electronic Center Control™ Panel with LED Display Smart Pairing

Advanced Drying - Al Sensor  $Dry^{TM}$  and  $TurboSteam^{TM}$ 

Advanced AI DD™ Washing - TurboWash® 360 and Steam Technology AAFA Certified Washer with Allergiene™ Cycle

Tempered Glass Door

ENERGY STAR® Certified

ThinQ® Technology with ThinQ Care



# **Proactive Smart Alerts to Keep** Your Appliances Running Smoothly

- Preventative Alerts help you stay a step ahead of potential issues to find proactive solutions before problems arise.
   Avoid preventable repairs and service calls with real-time diagnostics for a hassle-free experience.
   Integrated within LG's ThinQ app—a smart home hub for managing your smart devices and appliances.











	Washer	Dryer
Туре	Front Load Washer Front Load Drye	
Capacity (cu.ft.)	4.5 cu.ft.	7.4 cu. ft.
Color	White (W), Black Steel (B), Nature Green (G), Candy Apple Red (R)	
APPEARANCE	Washer Dryer	
Touch Buttons	Y	es
Full Touch Electronic Control Panel with LED Display	Y	es
Center Control™	Y	es
ENERGY	Washer	Dryer
ENERGY STAR® Certified	Y	es
CEE Tier	Tier 2	-
IMEF	2.92	-
IWF	2.9	-
CEF	-	Electric: 3.94 Gas: 3.49
PROGRAMS	Washer	Dryer
No. of Programs	6	6
	Normal, Bedding, Delicates, Heavy Duty, Speed Wash®, Downloaded	Normal, Bedding, Delicates, Heavy Duty, Small Load, Downloaded
OPTIONS	Washer	Dryer
No. of Options	10	9
	TurboWash®, Steam, Extra Rinse, Pre- wash, Sanitary*, Tub Clean*, Drum Light*, Control Lock*, Signal*, Wi-Fi* / Remote Start*	Wrinkle Care, Steam, Reduce Static, Energy Saver, Steam Fresh*, Drum Light*, Control Lock*, Signal*, Wi-Fi* / Remote Start*
DETAILS	Washer	Dryer
No. of Wash/Rinse Temps	5	-
Wash/Rinse Temps	Hot, Very Warm, Warm, Cool, Cold	-
No. of Spin Speeds	5	-
Spin Speeds	High, Medium/High, Medium, Low, No Spin	-
Max RPM	1300	-
Water Levels	Load Sensing	-
No. of Soil Levels	5	-
Temperature Settings	-	High, Medium/High, Medium, Low/ Medium, Low
Drying Levels	-	Very, More, Normal, Less, Damp
		60 min., 50 min., 40

TABILIC CARE LEATORES	vvasiiei	Diyei
AI DD™	Yes	-
TurboWash® 360 Technology	Yes	-
Steam Technology	Yes	-
Allergiene™ Cycle	Yes	-
Sanitary Cycle	Yes	-
Al Sensor Dry™	-	Yes
Sensor Dry		Yes
Precise Temperature Control with Variable Heater	-	Yes
Steam Technology	-	Yes (TurboSteam™)
CONVENIENCE FEATURES	Washer	Dryer
Vibration Sensing (Cabinet Vibration Sensor)	Yes	-
True Balance® Anti-Vibration System	Yes	-
4 Tray Dispenser	Prewash, Main Wash (with liquid detergent cup), Bleach, Fabric Softener	-
End of Cycle Signal	Yes	-
LoadSense	Yes	-
Control Lock	Yes	5
Auto Suds Removal	Yes	-
Leveling Legs	4 Adjustable Legs	
Drum Light	Yes	5
Remaining Time Display/Status Indicator(s)	Yes	5
3 Minute Installation Check	-	Yes
End of Cycle Signal	-	Yes
FlowSense® Duct Clogging Indicator	-	Yes
Wrinkle Care Option	-	Yes
Venting Option	-	Electric: 3 Way Venting / Gas: 2 Way Venting
ThinQ® TECHNOLOGY	Washer	Dryer
SmartDiagnosis™ (v3.0)	Yes	
Wi-Fi	Yes	5
Remote Start and Cycle Monitor	Yes	5
Energy Monitoring	Yes	5
Tub Clean Coach	Yes	-
MOTOR AND AGITATOR	Washer	Dryer
Motor Type	Inverter Direct Drive Motor	-
Axis	Horizontal	-

WATERIALS AND FINISHES	wasiiei	Di yei
NeveRust® Stainless Steel Drum	Y	es es
Cabinet	Painted Steel	
Control Panel	Plastic	
Top Plate	St	eel:
Door / Rim		le Chrome / ature Green only)
Door Cover	Tinted Round	Tempered Glass
All Available Colors		Black Steel (B), Candy Apple Red (R)
CERTIFICATION	Washer	Dryer
AAFA	Yes	-
POWER SOURCE	Washer	Dryer
Ratings	CSA	Listed
Electrical Requirements	120V, 10 Amps	240V, 30 Amps (Electric) / 120V, 15 Amps (Gas)
Туре	Electric	Electric / Gas
BTU Rating	-	Elec : N/A / Gas : 20,000
LP Conversion Kit	-	383EEL3002D
Side Venting Kit	-	3911EZ9131X
DIMENSIONS	Washer	Dryer
Product (WxHxD)	27" x 74 3/	'8" x 30 3/8"
Depth with Door Open	55" D with	n door open
Carton (WxHxD)	30 1/16" x 7	9 11/32" x 32"
Weight (Product/Carton)	311 lbs.	/ 346 lbs.
LIMITED WARRANTY	Washer	Dryer
Parts and Labor	1.	⁄ear
Direct Drive Motor	10 Years	=
Drum	3 Years	
UPC CODES		
WKEX200HWA (White)		048231028462
WKGX201HWA (White)		048231029261
WKEX200HBA (Black Steel)	048231028486	
WKGX201HBA (Black Steel)		048231029254
WKEX200HGA (Nature Green)	195174042687	
WKGX201HGA (Nature Green)		195174042694
WKEX200HRA (Candy Apple Red)	d) 195174043080	
WKGX201HRA (Candy Apple Red)		195174043110



# Café™ Beverage Center

# CCP06BP4PW2 / CCP06BP3PD1 / CCP06BP2PS1





# ALSO AVAILABLE IN

CCP06BP2PS1 Stainless Steel with Brushed Stainless handles



CCP06BP3PD1 Matte Black with Brushed Stainless handles

CCP06BP4PW2 Matte White with Brushed Bronze handles







# FEATURES & BENEFITS

Total Capacity: 5.1 Cu. Ft.

Capacity: 126 Cans/14 Bottles

ADA Compliant: Yes

Energy Star: Yes

BI capable: Yes

Door Type: Glass Reversible Door: Yes

Shelf Type: 3 Spill Proof/3 Glass/2 Wine Racks

Smart Capable: Yes

Freezer: No

Control Type: Electronic

Internal Lighting: LED Light Wall

Triple Pane Glass Door: The triple pane glass door improves temperature stability, reduces condensation and enhances energy efficiency compared to a double pane glass door.

# **FEATURES**

I LITT OTELO	
Control Type	Electronic
Interior Lighting	LED / LED Light Wall
Leveling System	Leveling Legs
Defrost Type	Automatic
Sabbath Mode	Yes

## **CAPACITY**

Total Capacity (cubic feet)	5.1 cu ft

# **WEIGHTS & DIMENSIONS**

Approximate Shipping Weight	147 lb
Net Weight	137 lb
Depth Without Handle	23 3/8 in
Overall Depth	26 in
Overall Height	34 1/8 in
Overall Width	23 3/4 in

# Café<sup>TM</sup> Beverage Center


CCP06BP4PW2 / CCP06BP3PD1 / CCP06BP2PS1



# WARRANTY

Warranty notes	See written warranty for full details
Labor warranty	Limited 1-year entire appliance
Parts warranty	Limited 1-year entire appliance
Parts warranty	Limited 5-year sealed refrigerating system

## **DIMENSIONS**



Overall Dimensions	Height (in.) A	34 1/8
	Width (in.) B	23 3/4
	Depth (in.) C	26
	Case Depth Without Door (in.) D	21 3/4
	Depth Without Handle (in.) E	23 3/8

# **ADDITIONAL ACCESSORIES**









CXQW IH IPPBT Brushed Black



CXQWIHIPPCU Brushed Copper



CXQW1H1PPFB Flat Black



CXQW1H1PPCG Brushed Brass

# BX212 - INSERT RANGE HOOD

The BX212 features a convenient underside three-speed control. It remains hidden at eye level, enabling seamless cabinet arrangement. Effective mesh filters purify the air, accompanied by bright halogen bulbs for ample illumination.

# Green Features



3 Speed Push Button Control 22" only



Long- lasting LED lights



3 Speed Slide Control Panel 28" & 34" only



Grease Cup

# Cyclone®



28"/34" (34" includes 3 filters)



22"

# Features

- · Insert range hood
- 6" round duct adapter
- · Non- stick Aluminium fan blades
- 3-speed push button control
- 3 speed slide control for 28" and 34"
- · Quick-release Aluminium Mesh/ Stainless Steel Baffle filters
- 2 halogen light bulbs (2 x 25W E26)
- · Plug-in connection

# Specifications

Air Flow Volume: 300 CFMElectrical Connection: 120 V/60 Hz

Power Consumption: 300 WattsCurrent: 2.5 Amps

• Fan Speed: 1350 RPM


• Fan Type: Centrifugal Blower

· Finishes: Stainless Steel

• Ducting: 6" Round

 Noise Level: Min. 2 Sones Max. 4 Sones

ISOMETRIC



# Options

· Filters: Aluminium Mesh Filters

• Widths: 30", 36"

• Finish: Stainless Steel

Model	Colour	Ducting	Filters	Size	CFM	Fits Cabinet
BX21222	Stainless Steel	6"	Mesh	22"	300	24"
BX21228	Stainless Steel	6"	Mesh	28"	300	30"
BX21234	Stainless Steel	6"	Mesh	34"	300	36"

Cyclone Range Hoods

www.CycloneRangeHoods.com

Toll free- 888.293.5662