


DELETE STANDARD PANTRY TO UPGRADE TO EXTENDED PANTRY
2755

780 800 400 775
30 750 600 600 750 25




EXTENDED PANTRY OPTION
OPTION #1

26

DELETE STANDARD PANTRY TO UPGRADE TO EXTENDED PANTRY
2755


30 900 900 900 25




EXTENDED PANTRY OPTION
OPTION #2

DELETE STANDARD PANTRY TO UPGRADE TO EXTENDED PANTRY
2755

30 750 800 400 750 25
30 750 600 600 750 25



EXTENDED PANTRY OPTION
OPTION #3



26

