

Simone Walker

From: Simone Walker
Sent: November 4, 2022 9:45 AM
To: Vince Roti; Katlyn Title (ktitle@newimagekitchens.ca); Fil Palmieri (fil@avclassictile.com); Luisa (luisa@avclassictile.com)
Cc: Anthony Petta; Laura Polsinelli (laura@zancorhomes.com); Bea Slipska (Beata@zancorhomes.com); Simone Walker
Subject: 59B Caledon APPLIANCE SPECS
Attachments: LOT 59B COOK TOP.pdf; fisher paykel fridgelOT 59B.pdf; microwave LOT 59B.pdf; LOY 59B WALL OVEN.pdf; dishwasherLOT 59B.pdf
Importance: High

Hello Everyone –

Attached are the appliance specs for 59B Caledon.

*****PLEASE NOTE – the front of the range style cooktop is to have QUARTZ AROUND/BEHIND THE KNOBS – please ensure that all accommodations are made for this.**
See image below for a reference.

59B
Appliances



Thank you,

Simone Walder

Zancor Homes

Décor Manager

C: (416) 843-7270 | O: (905) 738-7010

221 North Rivermede Rd.

Concord, Ontario L4K 3N7

Web: www.zancorhomes.com



CONFIDENTIALITY NOTICE: This email message, including any attachments, is for the sole use of the intended recipient(s) and may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited. If you are not the intended recipient, please reply to the sender by email and destroy all copies of the original message.



CG365C/S

FEATURES


- 20,000 Btu burner for faster boils
- Lower tier of dual-stacked burner lets you simmer and melt
- Continuous cast-iron grates for easy movement of pots and pans
- Spark ignition system re-ignites when flame goes out
- Dual-stacked, sealed burners for higher highs, lower lows
- Easy-clean seamless burner pan
- Illuminated control knobs
- Stunning minimalist design sits virtually flush to countertop
- Rigorously tested in our U.S. manufacturing facilities for decades of use
- Exceptional 24/7 support from our Customer Care team in Madison

ACCESSORIES

- Center burner wok grate
- Signature red, black or brushed stainless control knobs
- High altitude conversion kit


Accessories available through an authorized Sub-Zero dealer.
For local dealer information, visit subzero-wolf.com/local.

Lot 5913



KNOB OPTIONS

TOP CONFIGURATION



COOKTOP SPECIFICATIONS

- 2 - 9,200 Btu Burner
- 2 - 12,000 Btu Burner
- 1 - 20,000 Btu Burner


36" CONTEMPORARY GAS COOKTOP - 5 BURNERS

POLE


PRODUCT SPECIFICATIONS

Model	CG36SC/S
Dimensions	36 15/16" W x 6 3/4" H x 20 15/16" D
Weight	100 lb
Electrical Supply	120 VAC, 60 Hz
Electrical Service	15 amp dedicated circuit
Gas Supply	3/4" rigid pipe
Gas Inlet	1/2" NPT male
Power Cord Length	6 feet
Receptacle	3-prong grounding-type




ELECTRICAL AND GAS



DIMENSIONS



FLUSH INSTALLATION



NOTE: Shaded area above countertop indicates minimum clearance to combustible surfaces, combustible materials cannot be located within this area.
Maximum facade thickness 4" (101).
Outside corner radius 3/8" (10).

20659B

59B

Integrated French Door Refrigerator Freezer, 36", Ice & Water

Series 7 | Integrated

Panel Ready




This large capacity refrigerator with bottom freezer seamlessly integrates into your kitchen, fitting flush into your cabinetry.

- ActiveSmart™ technology helps keep food fresher for longer by constantly maintaining the ideal temperature
- Stainless steel door panel purchased separately – with water dispenser option available
- Internal ice maker with boost for busy times
- Can be fitted for a height of 80 or 84 inches

DIMENSIONS

Height	79 27/32"
Width	35 21/32"
Depth	23 3/4"



FEATURES & BENEFITS

ActiveSmart™ Foodcare
ActiveSmart™ Foodcare learns how you live. It's technology which understands how you use your fridge and adjusts temperature, airflow and humidity inside to help keep food fresher for longer.

Easy cleaning
No more permanent dirty marks with our EZKleen feature for stainless steel refrigerators. Anti-fingerprint coating means you

simply wipe clean any marks. Spill-safe secure glass shelves easily capture any drips or leaks.

Water on tap

The slimline dispenser makes it easy to fill almost any sized jug or vessel with cool filtered water and doesn't take up any storage space in your refrigerator.

Ice maker

Fresh ice is always available for you in a dedicated freezer bin. Simply turn it off to free up freezer space or during busy times, you can boost ice production by up to 30%.

Design quality

Our refrigerators are designed and built using quality materials. We use real stainless steel on our refrigerators and solid glass for shelving.

Simple storage

This refrigerator is designed to make it simple for you to store, access and remove food. Storage bins give you full access inside when they're pulled open and can be easily removed to clean. Our flexible shelving also gives you more storage options.

Complementary Design

With their premium handle styling and stainless steel finish, our refrigerators are designed to match the rest of Fisher & Paykel's kitchen appliance family.

SPECIFICATIONS

Accessories	Capacity
Contemporary round handle kit 25374 sold separately	Matching Replacement Water Part number 842802
	Stainless steel door panel set, RD3680U
	Stainless steel door panel set, RD3684U

Freezer	5.1cu ft
Refrigerator	11.7cu ft
Total	16.8cu ft

Freezer features	
Bottle chill	•
Built-in ice maker	•
Fast freeze	•
Frost free freezer	•
Large plastic bin	•
Small plastic bins	1

Performance	
ActiveSmart™ Foodcare	•
ActiveSmart™ technology	•
Adaptive defrost	•
Frost free freezer	•
Humidity control system	•
Sabbath mode	•

Product dimensions	
Depth	23 3/4"
Height	79 27/32"
Width	35 21/32"

Refrigerator features	
Adjustable door shelves	6
Adjustable glass shelves	3
Cantilevered Shelves	•
Covered door shelves	2

FISHER & PAYKEL

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2019.

Deli storage bins	1
Door alarm	•
Fruit and vegetable bins	2
LED lighting	•
SmartTouch control panel	•
Soft close doors	•
Stackable bottle holders	4
Ultra slim water dispenser	•

Warranty	
Parts and labor	2 years
Sealed system parts only	5 years

SKU	
25073	



A PEACE OF MIND SALE
24 Hours 7 Days a Week Customer Support
T 1300 650 590 W www.fisherpaykel.com

24/7

30" E SERIES TRANSITIONAL DROP-DOWN DOOR MICROWAVE OVEN



MD D30TE/S/TH


FEATURES

- Distributes heat evenly with no hot or cold spots allowing for oven-like operation
- Installs standard or flush to conceal the oven from view
- Matches E series ovens, coffee systems, convection steam oven
- Utilizes 900 watts of power to cook meals with delicious results
- Select from 10 power levels, a warming mode, and sensor cooking
- Rely on quick-start controls for tasks like melting, softening, defrosting, and popcorn
- Let the microwave do the cooking with intuitive "gourmet mode" settings
- Install into surrounding cabinetry to coordinate with other Wolf built-in ovens and warming drawers

ACCESSORIES

Side Trim

Accessories available through an authorized dealer.
For local dealer information, visit subzero-wolf.com/locator.



59/16

Specifications are subject to change without notice. This information was generated on November 3, 2022. Verify specifications prior to finalizing your cabinetry/enclosures.

30" E SERIES TRANSITIONAL DROP-DOWN DOOR MICROWAVE OVEN



PRODUCT SPECIFICATIONS


Model	MDD30TE/S/TH
Dimensions	29 7/8"W x 17 7/8"H x 20"D
Capacity	1.6 cu. ft.
Door Clearance	14 3/16"
Electrical Supply	120 VAC, 60 Hz
Electrical Service	15 amp dedicated circuit
Power Cord Length	4 Feet
Receptacle	3-prong grounding-type

ELECTRICAL




NOTE: Dimensions in parenthesis are in millimeters unless otherwise specified

DIMENSIONS



FLUSH INSTALLATION



***Will be visible and should be finished to match cabinetry.**

****Dimension provides minimum reveals.**

Specifications are subject to change without notice. This information was generated on November 3, 2022. Verify specifications prior to finalizing your cabinetry/enclosures.

30" E SERIES TRANSITIONAL BUILT-IN SINGLE OVEN



SO3050TE/S/T



FEATURES

- Wolf's dual convection system provides reliably even heat, reduces hot and cold spots, and enables consistent multi-rack cooking
- Ten cooking modes, including Bake, Broil, Convection, Convection Roast, Dehydrate, Gourmet, Proof, Roast, Stone, and Warm, were developed by Wolf chefs to maximize the performance of your oven
- Gourmet Mode offers nearly 50 presets to automatically cook a delicious set of impressive dishes
- The large full-color touch screen and stainless touch controls are intuitive and easy-to-read
- The temperature probe alerts you when your dish has reached the desired temperature.
- The oven offers self-clean, delayed start, timed cook, and Sabbath features
- The Wi-Fi enabled feature lets you remotely preheat, select modes, and adjust oven temperature from your mobile device
- Coordinates with other Sub-Zero, Wolf, and Cove appliances to create a cohesive look in your kitchen
- Get the most out of your oven with tips and recipes from the Mastering the E Series Oven guide

ACCESSORIES

30" Broiler Pan	
30" Premier Baking Sheet	
30" Standard Oven Rack	
Bake Stone Kit	
Dehydration Kit	
Dual Installation Kit	
Full-Extension Ball-Bearing Rack	
Standard Oven Rack	
Temperature Probe	

Accessories available through an authorized dealer.
For local dealer information, visit subzero-wolf.com/locator.



5916

Specifications are subject to change without notice. This information was generated on November 3, 2022. Verify specifications prior to finalizing your cabinetry/enclosures.


30" E SERIES TRANSITIONAL BUILT-IN SINGLE OVEN



PRODUCT SPECIFICATIONS


Model	SO3050TE/S/T		
Dimensions	29 7/8"W x 28 1/2"H x 23"D		
Oven 1 Interior Dimensions	25 1/4"W x 17 1/2"H x 18 1/2"D		
Overall Capacity	4.7 cu. ft.		
Usable Capacity	3.1 cu. ft.		
Door Clearance	21 3/8"		
Weight	257 lbs		
Electrical Supply	240/208 VAC, 60 Hz		
Electrical Service	30 amp dedicated circuit		
Conduit Length	4 Feet		

ELECTRICAL




NOTE: Dimensions in parenthesis are in millimeters unless otherwise specified

DIMENSIONS



FLUSH INSTALLATION



*Shaded areas will be visible and should be finished to match cabinetry.
**Dimension provides minimum reveals.
NOTE: Location of electrical supply within opening may require additional cabinet depth.

FISHER & PAYKEL

9/15/15

DOUBLE DISHDRAWER™ DISHWASHER

DD24DDFT & DD24DV2T
models


INSTALLATION GUIDE

US CA



591385C 05.19

Dis/Novaline
20659B

4 PRODUCT DIMENSIONS



PRODUCT DIMENSIONS	INCHES (MM)	INCHES (MM)
A Overall height of product ¹	34 - 36 3/8" (864-924) ²	DD24DDFT
B Overall width of product	23 9/16" (599)	DD24DV2T
C Overall depth of product (excl. handle)	22 3/4" (573)	
D Depth of chassis (to back of front drawer panel)	21 3/4" (553)	
E Depth of drawer front panel (excl. handle)	13/16" (20)	
F Height of drawer front panels	33 11/16" (855)	
G Height of upper drawer front panel	17 3/8" (442)	
H Height of lower drawer front panel	12 1/4" (312)	
I Height from top of drawer front panel to top of chassis	1/16" (2)	
J Ventilation gap between drawer front panels	5/16" (8)	
K Height of toe kick (customisable)	2 13/16 - 5" (72-127)	
L Depth from front of drawer panel to front of toe kick (adjustable) ³	1 1/2 - 4" (38-102)	
M Maximum extension of drawer	3/8 - 2 3/4" (9-69) ²	
N Height of leveling feet (adjustable)	3/8 - 2 3/4" (9-69) ²	
O Includes 1/16" (2mm) high bracket slots ² depending on adjustment of leveling feet	21 9/16" (547)	
P adjustable to match toe kick recess on adjoining cabinetry	21 9/16" (547)	



IMPORTANT SAFETY INSTRUCTIONS

- Installation of this dishwasher requires basic mechanical and electrical skills.
- Be sure to leave these instructions with the Customer.
- Installation must comply with your local building, electrical, and plumbing regulations.
- At the completion of the dishwasher installation, the installer must perform the Final Checklist.
- Remove all packaging materials supplied with the dishwasher.
- This dishwasher is manufactured for indoor use only.
- Ensure all water connections are turned OFF. It is the responsibility of the plumber and electrician to ensure that each installation complies with all Codes and Regulations.
- The dishwasher MUST be installed to allow for future removal from the enclosure if service is required.
- The switched power outlet must be outside the dishwasher cavity, so that it is accessible after installation.
- Care should be taken when the appliance is installed or removed to reduce the likelihood of damage to the power supply cord and hoses.
- If the dishwasher is to be relocated from one installation to another it must be kept upright to avoid damage from water spillage.
- Make sure only new hoses are used for connection (supplied with the dishwasher).
- Old hoses should not be reused.
- Failure to install the dishwasher correctly could invalidate any warranty or liability claims.
- If the product is installed in a motor vehicle, boat or similar mobile facility, you must bring the vehicle, boat or mobile facility containing the product to the service shop at your expense or pay the service technician's travel to the location of the product.
- This dishwasher is intended for connection to the hot-water supply.

10/15

**WARNING!**

Electrical Shock Hazard

Before installing the dishwasher, remove the house fuse or open the circuit breaker. If permanently connecting the dishwasher, be sure the power is isolated and the dishwasher unplugged.

GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This appliance is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is installed and grounded in accordance with all local codes and ordinances. **WARNING** - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service representative if you are in doubt as to whether the appliance is properly grounded.

If the dishwasher is installed as a permanently connected appliance: **GROUNDING INSTRUCTIONS** - This appliance must be connected to a grounded metal, permanent wiring system, or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment-grounding terminal or lead on the appliance.

Do not modify the power supply plug provided with the appliance - if it will not fit the outlet, have a proper outlet installed by a qualified electrician. Do not use an extension cord, adapter plug or multiple outlet box.

Failure to follow this advice may result in electrical shock or death.



**WARNING!**

Cut Hazard

Take care - panel edges are sharp.

Failure to use caution could result in injury or cuts.





IMPORTANT!
SAVE THESE INSTRUCTIONS

The models shown in this installation guide may not be available in all markets and are subject to change at any time. For current details about model and specification availability in your country, go to our website www.fisherpaykel.com or contact your local Fisher & Paykel dealer.


3 ③ OPTIONALLY HARD WIRING PRIOR TO INSTALLATION

3-A REMOVE THE LOWER DRAWER



To prevent kinked hoses
Either sit the drawer down on the left
hand side (recommended) or rotate the
drawer clockwise, resting it on its side after
removal.



- 1 With a flat-bladed screwdriver, push in the clips and slide out the access cover.
- 2 Unscrew the electronics module cover.
- 3 Carefully pull out the electronics module and rest on the chassis base out of the way.
- 4 With a screwdriver, unclip the plastic harness cover and hinge open. Slide the terminal block cover open sideways to unlock and hinge open to access the terminal block.
- 5 Unscrew the Live, Neutral and Earth wires as shown.
- 6 Unscrew the three screws on the base as shown and remove the cord from the product.



3-B REMOVE THE ACCESS COVER & REMOVE POWER CORD






59B

3 OPTIONALLY HARD WIRING PRIOR TO INSTALLATION

3-C TERMINATE MAINS WIRING AS SHOWN AND REPLACE MODULE AND COVERS

- 8 Fit a suitable cable clamp for the conduit through the metal knockout. Ensure wiring is routed through or under under housing ribs.
 - 9 Screw down the Live, Neutral and Earth wires correctly.
 - 10 Push the plastic harness cover back over. It should clip back into place.
 - 11 Fold down and slide back the terminal block cover.
 - 12 Refit the electronics module back into position, being careful of wiring.
 - 13 Replace the screw securing the electronics module.
 - 14 Slide the access cover back, ensuring the 2 clips shown are fully locked in place.
- NOTE: Use copper conductors only.





IMPORTANT!




Ensure the mains wires are routed UNDERNEATH all other harness wiring from the electronics module.

3-D REFIT THE DRAWER ONTO THE RUNNERS & CLOSE

Pull the release tabs forward on both sides 4" (100 mm). Ensure the tabs are fully pulled forward and click into place.



Lift or rotate counter-clockwise the drawer back onto the drawer runners on either side.



Before refitting the drawer, ensure the hoses are not twisted and the latches at the rear of each drawer runner are facing forward.



Water Connection
Recommended **HOT**
(Maximum 140°F/60°C).
Supplied hose to
suit 3/8" (9 mm) male
compression fitting.

Water Pressure
Water softener models
Max. 1 MPa (145 psi)
Min. 0.1 MPa (14.5 psi)
Models without water softener
Max. 1 MPa (145 psi)
Min. 0.03 MPa (4.3 psi)

Kosher requirements


Drains will need to be
separated to satisfy
kosher requirements.
We suggest you confirm
acceptability with your
local rabbi in respect to
kosher installations.

IMPORTANT!
The power outlet must be
located in a cabinet adjacent
to the dishwasher cavity.
110-120 VAC max. 15 A



These marks indicate formed
bracket screw locations, if
securing by drawer removal.
If there is no side partition, you
can construct timber bracing
as something to secure into.

WARNING!
Incorrect placement of the hole
will result in damage to hoses.



- Service Holes**
Can be located either side of dishwasher, close to the rear face and the floor, as illustrated, for access to the water supply, drain and power outlet. The small hole is for the power cord only.
- If the hole is through wood, make sure its edges are smooth and rounded to prevent damage to the power cord.
 - If the hole is through metal, ensure you fit the supplied Edge Protector to